

ELI-S-20


20 OR 25 W BACKUP MICRO INVERTER

PHILIPS
bodine

Installation Instructions

UNIVERSAL INPUT, SINE WAVE OUTPUT,

ELI SERIES EMERGENCY LIGHTING EQUIPMENT INVERTER SINUSODIAL



! IMPORTANT SAFEGUARDS !


WHEN USING ELECTRICAL EQUIPMENT, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

1. Caution:

- High voltage will be present on the output wires and terminals if batteries are installed and inverter connector is joined or if AC power is supplied to the switched and unswitched terminal.
 - Ensure input and output primary wiring connections are made to the proper terminals. Damage to product may occur if miswired.
2. To prevent high voltage from being present on the orange/black and yellow/black output leads prior to installation, inverter connector must be open. Join inverter connector after the backup micro inverter has been installed and before the AC power is supplied.
 2. For use with fluorescent, incandescent or LED fixtures up to 20 W (0°C to 50°C including driver/ballast) at unity power factor for UL and CSA. This product is also rated up to 25 W (0°C to 45°C including driver/ballast) at unity power factor for UL only.
 3. Make sure all connections are in accordance with the National Electrical Code or Canadian Electrical Code and any local regulations.
 4. To reduce the risk of electric shock, disconnect both normal and auxiliary power supplies and inverter connector of the backup micro inverter before servicing.
 5. This backup micro inverter is for factory or field installation.
 6. An AC power source (120, or 277 VAC, 60 Hz) ahead of any wall switch is required to provide battery charging current.
 7. Do not install near gas or electric heaters.
 8. This product is for use with indoor or damp locations where ambient temperature is 0°C to 50°C. Not suitable for wet or hazardous locations.
 9. This is a sealed unit. Integral battery is not replaceable. Replace entire unit when necessary.
 10. The use of accessory equipment not recommended by the manufacturer may cause an unsafe condition.
 11. Do not use this product for other than intended use.
 12. Servicing should be performed by qualified service personnel.
 13. Equipment should be mounted in locations and at heights where it will not be subjected to tampering by unauthorized personnel.

SAVE THESE INSTRUCTIONS




Ni - Cd

THIS PRODUCT CONTAINS A RECHARGEABLE NICKEL-CADMIUM BATTERY.
THE BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY.

02/15/18

© Philips Emergency Lighting

INSTALLATION



WARNING: TO PREVENT HIGH VOLTAGE FROM BEING PRESENT ON THE ORANGE/BLACK AND YELLOW/BLACK OUTPUT LEADS PRIOR TO INSTALLATION, INVERTER CONNECTOR MUST BE OPEN. JOIN INVERTER CONNECTOR AFTER INSTALLATION IS COMPLETE AND AC POWER IS SUPPLIED.

NOTE: Make sure that the necessary branch circuit wiring is available. An unswitched source of power is required. The unswitched and switched power source must be fed from the same branch circuit.

INSTALLING THE BACKUP MICRO INVERTER

- > The backup micro inverter will be located between the AC power sources and the AC ballast/driver as shown in wiring diagram section of instructions.
- > **NOTE:** The backup micro inverter may be installed in close proximity to the fixture or remote from the fixture. The maximum remote distance using 16 AWG wire is 250 ft. Contact the factory for more information.
- > The AC power is fed to the backup micro inverter.
- > The AC ballast/driver receives power from the backup micro inverter. Identify the output wires of the backup micro inverter by the presence of the orange/black and yellow/black leads.

STEP #1 ► DISCONNECT AC POWER FROM FIXTURE

- > Disconnect all power sources from lighting fixture and ensure they are locked out during installation or maintenance.
- > Disconnect power leads from the AC ballast/driver.
- > Select a suitable location for the backup micro inverter and install such that its output leads can connect to the input leads of the AC ballast/driver.
- > See Illustration 1, for typical installation and select appropriate mounting method.

STEP #2 ► CONNECT THE BACKUP MICRO INVERTER TO THE PROPER LINE VOLTAGE

- > Verify that the inverter connector (red and white) is disconnected. Note that the unswitched hot connects to the black input lead of the backup micro inverter.


STEP #3 ► WIRING THE BACKUP MICRO INVERTER

- > Use the wiring diagram found on page 4 as reference.
- > Connect the AC power source leads to the input of the backup micro inverter.
- > Connect the output leads of backup micro inverter to the AC ballast/driver.
- > Wire the AC ballast/driver with the lamp in accordance with manufactures installation instructions. No ballast/driver is necessary for incandescent lamp application.
- > Make sure all connections are in accordance with the National Electrical Code, Canadian Electrical Code and any local regulations.
- > Connect the indicator LED by matching violet and brown leads.
- > In a readily visible location, attach the label "CAUTION-This Unit Has More Than One Power Connection Point. To Reduce The Risk Of Electric Shock, Disconnect Both The Branch Circuit-Breakers Or Fuses And DC Power Supply (Backup Ballast Inverter Connector) Before Servicing."

INSTALLATION

STEP #4 ► JOIN THE INVERTER CONNECTOR & APPLY POWER

- > After installation is complete, join the inverter connector and apply AC power.
- > At this point, power should be connected to both the AC ballast and the backup micro inverter, and the Charging Indicator Light should illuminate indicating the battery is charging.
- > A short-term discharge test may be conducted after the backup micro inverter has been charging for 1 hour. Charge for 24 hours before conducting a long-term discharge test. **Refer to OPERATION.**



† The T-BAR mounting bracket assembly is sold separately and is available from the factory as an accessory kit (T-BAR-MB). Call your local distributor or the factory for complete information.

 Backup Micro Inverter

 No Shading – Equipment supplied by others

- ① – Flexible conduit (supplied) to connect ballast wires.
- ② – Existing conduit to run existing wires to lamp holder.
- ③ – AC line in.
- ④ – Conduit and junction box (not supplied).

OPERATION

During normal operation, AC power is supplied to the AC ballast/driver through the backup micro inverter and the inverter charges the battery. Connecting the inverter connector wires (red and white) enables the emergency circuit and supplies power to the control/monitor circuit. The backup micro inverter detects AC input line voltage (120/277) and automatically sets the output voltage during emergency mode.

When AC power fails, the backup micro inverter automatically switches to emergency mode, keeping the load illuminated for a minimum of 90 minutes. When AC power is restored, the backup micro inverter returns to charging mode. The backup micro inverter consists of a low-battery voltage disconnect which is reset when AC power is restored. The unit can also detect an abnormal load condition (open or shorted load) during emergency mode operation and will protect the inverter from damage.

MAINTENANCE

Although no routine maintenance is required to keep the backup micro inverter functional, it should be checked periodically to ensure that it is working. The following schedule is recommended:

1. Visually inspect the charging indicator light monthly. It should be illuminated.
2. Test the emergency operation of the fixture at 30-day intervals for a minimum of 30 seconds. The lamp should operate at full illumination.
3. Conduct a 90-minute discharge test once a year. The lamp should operate at full illumination for at least 90 minutes.

! REFER ANY SERVICING INDICATED BY THESE CHECKS TO QUALIFIED PERSONNEL !

BACKUP MICRO INVERTER AND AC BALLAST/DRIVER MUST BE FED FROM THE SAME BRANCH CIRCUIT

TYPICAL SCHEMATICS ONLY. CONSULT THE FACTORY FOR OTHER WIRING DIAGRAMS.

WIRING DIAGRAM

